


**DISPLAY** **A**

Watch hands




30 minutes counter  
Day indicator  
Month indicator  
Hour hand  
Minute hand  
Push-button A  
Push-button B  
24 h hand  
60 seconds counter  
12 hours counter  
Moon phase indicator  
Date hand  
Setting crown (position I, II, III)  
Second hand  
Push-button C

**SETTINGS** **B**

Crown 3 positions

Push-button C  
Quick correction of day  
Day correction is not possible between 9.30 p.m. and 12 o'clock midnight

Date correction is not recommended between 10 p.m. and 2 p.m.  
The moon phase cannot be corrected between 3 a.m. and 4 a.m.




Normal running of watch and hand-winding  
Rapid correction of moon phase  
Position for setting the time with stop second and correction of the date at every passing of midnight

**Self-winding of the watch by the movements of the wrist.**

**TIMING MODE** **C**

Simple timing function




START  
STOP  
Read time  
- 4 hours  
- 10 minutes  
- 19 seconds  
Reset to zero  
Setting crown in position I

**1 to 3 order of functions**

**TIMING MODE** **D**

ADD function



START  
STOP  
Read  
RESTART  
STOP Read  
RESTART  
STOP Read  
Reset to zero

**1 to 3 order of functions**